



FLEX

Instruction

- ① FLEX RAIL 60 cm - 48 cm
FLEX RAIL 40 cm - 26 cm




- ② Screw until 1 cm from the wall.
Skrú indtil 1 cm fra væggen.




GEJST

3



4



5

