

Sheepskin


In order to preserve the original condition of your sheepskin furniture, vacuum clean with a soft mouthpiece designed for furniture and air regularly. Spots should be immediately soaked with water. Clean with a sponge, luke warm water and a mild wool shampoo.

Avoid placing the furniture in direct sunlight as color changes in the wool may occur.

Fried Egg

Designed by
Hans Olsen
1956

Care Instructions



For more information about care and maintenance go to
www.warmnordic.com

Care Instructions

Warm Nordic's furniture is high quality when it comes to design and functionality.

With correct maintenance, the furniture will remain in good condition for many years to come. We advise that you follow the accompanying guidelines to care for and clean the furniture. This ensures extended life time.

We have chosen materials which age beautifully, but please be aware that all materials undergo changes to their nature over time when exposed to light, dust and use.

General advice

The legs are made from sustainable plantation teak which may be light, striped or even speckled at first but gets a more even and dark golden colour tone after exposure to sunlight and air for just a short period of time.

Whole or partial coverage with blankets or cushions for long periods of time can cause differences in the hue and colouration of the fabric.

Avoid placing furniture close to solid fuel stoves and radiators, as the heat source may dry out the wood and cause the formation of cracks.

Do not stand on the furniture or sit on the back or armrest.

Oiled teak

Teak is a natural material and for this reason may vary in colouration and structure. Oiled wood has a warm glow, which achieves a beautiful patina with regular maintenance.

Regular cleaning: To be wiped with a clean, lint-free cloth wrung out in warm water. Wipe with a dry cloth.

Do not use dish-soap or other detergents to clean and do not use abrasives such as scouring creams, steel wool or scouring sponges as these will cause scratches and drying out.

Maintenance: We recommend that the surface is treated at regular intervals with an oil specially designed for oil treated furniture, such as Guardian Wood Oil, which can be used on all 'hard' wood types.

Scratches: Small scratches can be bettered by sanding the wood with the grain with fine-grained sandpaper (grit 220). Following this, the oil treatment described above must be repeated.

Please note that the cloth may self-ignite and must therefore be disposed of or kept in an air-tight bag or container.

Guardian Wood Cleaner can be used beneficially before oil treatment in the case of difficult stains.

Textiles

The textiles used on Warm Nordic's products come from leading textile-manufacturers and are all of high quality.

Regular cleaning: Upholstered furniture should be vacuumed often with a soft mouthpiece designed for furniture. Always remove stains and liquids immediately to avoid these penetrating the material and leaving marks. Velvet textiles may also be brushed lightly after vacuuming with a hard cloth brush.

Textiles can be treated with Guardian Textile Protection to great advantage, substantially minimising the risk of stains.

Stain removal: Stains and spilled liquids should be removed immediately by dabbing with kitchen tissue or a dry, lint-free cloth. Stains which are not greasy can be removed by gently dabbing with a clean, lint-free cloth or sponge wrung out in clean, warm water. The stain should be agitated from the edge working towards the middle with clean, lint-free cloths. Do not rub, as this may damage the textile. The damp spot can be easily dried with a hairdryer on a low setting. Many stains require special treatment.

For difficult stains, we recommend the use of Guardian Textile Cleaner.

There is no one detergent which can remove all types of stain. Specific stains are not covered by this guide, and it may therefore be necessary to seek the aid of your furniture retailer.

Velvet: On velvets, which are not regularly maintained, the seat and back will be formed and will show pile tangling over a period of time. Depending on the colour, you will see it as a change of shade.

By sitting you exert pressure on the velvet fabric forcing the pile naps in any direction. In combination with heat, the rising air humidity, the body moisture and the kind of filling material under the velvet the direction changes of the pile naps is "partly fixed". This is a typical property of velvet fabric and it is neither a defect or a sign of low quality.

You can treat these marks of wear and tear as follows:

Take a clean, white (not coloured), warm, damp (not wet) piece of cloth and lay it several hours or a night over the velvet. The moisture will restore the cotton velvet. The velvet upholstery should not be used before it is completely dry!
