

**CLEANING / RENGØRING / SÄUBERN / NETTOYAGE / LIMPIEZA**

**EN:** TURN OFF ELECTRICITY, CLEAN WITH DRY OR MOIST CLOTH

**DK:** AFBRYD ELEKTRICITET, RENGØR MED TØR ELLER FUGTIG KLUD

**DE:** VOM STROM TRENNEN, MIT EINEM SAUBEREN, TROCKENEN ODER FEUCHTEN TUCH.

**FR:** COUPEZ L'ÉLECTRICITÉ ET NETTOYEZ AVEC UN CHIFFON SEC OU HUMIDE

**ES:** DESCONECTAR LA CORRIENTE ELÉCTRICA Y LIMPIAR CON EL PAÑO SECO O HÚMEDO

**INSPIRATION:**




*Scan to see our catalogue*

**MUUTO.COM**

ØSTERGADE 36-38  
1100, COPENHAGEN K  
DENMARK


# COSY IN WHITE LAMP



**MUUTO**

*New Nordic*

CONTENT / INDHOLD / INHALT / CONTENU / CONTENIDO:



LARGE

Item No: 01031  
Type: Cosy in white-large  
1XE27, bulb Min.25W-Max.60W  
Caution: Only dimmable bulb  
can be used  
220-240V, 50HZ



SMALL

Item No: 01032  
Type: Cosy in white - small  
1XE14, bulb Min.25W-Max.40W  
Caution: Only dimmable bulb  
can be used  
220-240V, 50HZ



ASSEMBLY INSTRUCTION / SAMLE MANUAL / MONTAGEANLEITUNG /  
INSTRUCTIONS DE MONTAGE / INSTRUCCIONES DE MONTAJE :

