


VIPP12 SUCTION HOOK INSTRUCTION GUIDE

USE

The Vipp suction hook is approved to carry up to 500 g., working most efficiently when placed on smooth, leveled surfaces such as glass, glazed tiles or high-shine spray-painted cabinets. The suction hook will not function properly if placed on porous or uneven surfaces. Sun and heat may cause the suction hook to fall off the surface. Should the suction hook fall off, simply put it back.

MOUNTING

Make sure the rubber surface of the suction hook is clean, dry and dust-free.



1. Mount the suction hook on the surface by applying pressure to the plastic hook.

2. Flip the plastic hook in place to secure the suction hook.

MAINTENANCE

Rubber

To ensure a minimum level of rubbing off, the rubber on the suction hook is free of softening agents. This can make the rubber prone to dryness, which may result in a loss of suction ability. Should this happen, clean the rubber surface of the suction hook with warm water and wipe it off with a moist cloth. Once the rubber surface is dry, apply a very thin layer of colourless Vaseline or silicone spray. Let the suction hook dry for 10 minutes before mounting it again.

Stainless steel

Keep stainless steel clean and dry. Stainless steel may be permanently stained if water/fat/cleaning products are not removed relatively quickly. We recommend the use of a care product for stainless steel to make the surface water and dirt repellent. This makes the regular cleaning with a damp, lint-free cleaning cloth much easier. If the above instructions are followed, the stainless steel surface will remain beautiful for many years. Remember not to use chlorine/abrasive cleaners as they may damage the stainless steel surface.

Tips for stains

Grease stains: Use alcohol or glass cleaner to remove grease stains. Then follow the guide for regular maintenance.

Lime stains and discolouration: Lime stains on stainless steel can be removed with warm soapy water, a soft sponge and a lot of elbow grease. It is important only to use a soft sponge to avoid damaging the brushed structure of the steel surface.

Stubborn stains and rust: Stubborn stains and rust may be removed by careful cleaning with a light-abrasive cleaner suitable for stainless steel. Cleaning must follow the structure of the polished surface. Please note that this process may change the original polishing of the surface.

DISCLAIMER

Please note that rubbing off from the rubber surface may occur after the application of vaseline or silicone spray. It is therefore advisable to test the suction hook on a hidden surface before mounting it. Do not place the suction hook on vinyl, linoleum, surfaces containing PVC or acid surfaces, as the rubber part of the suction hook may leave marks on such materials.